CHANGING LEVER HANDING



- A. Remove input shaft screw. (Remove input shaft if necessary).
- B. Remove stop plate.
- C. WARNING: Springs under pressure! Remove spring retaining plate. Carefully remove the springs.
- D. (For 09 Function only) Switch lock spring to opposite side.
- E. Remove top gear.
- F. Loosen the clutch center screw approximately two (2) turns. Bend locking tab back to disengage with notch.
- G. Slide the locking bar away from the rack (not necessary for 14 function). Remove the rack while rotating the lever.
- H. Continue rotating the lever to the opposite side.
- I. Rotate the lever to the position shown. Partially engage the rack and the clutch gear on the opposite side.
- J. Rotate the lever until the rack is completely seated.
- K. Insert the top gear.
- L. Add permanent thread locking adhesive and tighten the clutch center screw. Bend tab over screw notch so that screw cannot turn.
- M. WARNING: Springs under pressure! Install the springs. Hold the lever in the open position, firmly compressing the springs in place.
- N. While holding the lever in the open position, replace the spring retaining plate and fasten the two (2) screws.
- O. Reverse the stop plate and fasten the screw.
- P. Replace input shaft screw. Handing complete.



E-MAIL: detex@detex.com



08 or 09 LEVER TRIM

103129	September 14, 2009
--------	--------------------

Detex Corporation, 302 Detex Drive, New Braunfels, Texas 78130-3045 (830)629-2900 / 1-800-729-3839 / Fax (830)620-6711 INTERNET: www.detex.com INSTALLATION INSTRUCTIONS FOR MORTISE OUTSIDE LEVER TRIMS

> 08DM, 08DMT, 08DMU 09DM, 09DMT, 09DMU 14DM, 14DMT, 14DMU



14 LEVER TRIM

08, 09, 14 LEVER TRIM INSTALLATION INSTRUCTIONS

NOTES:

1

1) Mortise lock NOT supplied with TRIM device.

2) For a retrofit application, remove lock and device before installing new trim.

3) LHR installation shown (Reverse all steps for RHR).

STEP 1: PREP DOOR

TRIM side: Use plastic template to mark and drill TRIM holes





STEP 2: PREP TRIM DEVICE

ζ Install mortise cylinder and trim input shaft 2

NOTE:

2

- 1. Key should turn cylinder easily to slide locking bar in both directions.
- 2. Mortise cylinder installed on 08 & 09 trims only
- 3. Mortise cylinder NOT supplied with trim, but can be ordered separately



