



Keys, your number's up.

Schlage Touch™

With the Schlage Touch™ Keyless Touchscreen lock, there's no keyhole for intruders to pick or bump, and no need to ever rekey. Just use the fingerprint-resistant touchscreen to enter with an access code – no key necessary. All in a slim profile that's every bit as sleek as it is strong.

No more keys to lose, hide, carry or forget

- No key needed: use a convenient access code
- Works in the rain and with gloves
- Eliminates need to re-key or cut new keys
- 2-year battery life with low battery icon and 9V battery backup

Slim profile without sacrificing strength

- Easily fits between front door and screen door
- Available in a variety of styles and finishes to complement your home
- Sleek lever options coordinate with interior hardware

Choose your own access codes

- Create and delete codes for visiting friends and family
- Memory for 19 access codes


Easy installation

- Installs in minutes with a screwdriver - no wiring needed
- Guaranteed to fit on standard doors


Finishes

Function	605	608	609	613	618	619	620	622	625	626	716
BE375 Camelot	•		•					•	•	•	•
BE375 Century (CAM)											
FE695 Accent	•		•				•		•	•	•
FE695 Accent (CEN) Century	•		•								
FE695 Broadway									•	•	•
FE695 Elan											•
FE695 Latitude									•	•	•
FE695 Merano									•	•	•

Door preparation



Door Preparation



Schlage Touch™ deadbolts



BE375 Camelot (CAM)



BE375 Century (CEN)

Schlage Touch™ levers



FE695 Camelot x Accent (CAM) (ACC)



FE695 Camelot x Flair (CAM) (FLA)



FE695 Century x Broadway (CEN) (BRW)



FE695 Century x Latitude (CEN) (LAT)



FE695 Century x Merano (CEN) (MER)