

1. MOUNTING HOLES TO BE PREPARED AT INSTALLATION ON DOOR.
2. TRIM OR CONTROL APPLICATION MAY REQUIRE ADDITIONAL PREPARATION, SEE TRIM OR CONTROL DIRECTION SHEET.

3. DOOR EDGING SHOULD BE INSTALLED AFTER DEVICE INSTALLATION.

STD & CX98/9947WDC-F-LBR Series Device(Wood Door)

VON DUPRIN

TEMPLATE NUMBER:

W10323 a

DATE: 12-11-13