	Latch	Outside Knob/Lever*		Inside Knob/Lever	
Function	Operated by	Locked by	Unlocked by	Locked by	Unlocked by
DEL-Locked Fail Safe	Outside knob/lever when power is removed from the solenoid Outside key Inside knob/lever Latchbolt is deadlocked by an auxiliary latch	Applying power to the solenoid; remains locked while power is on.	Removing power from the solenoid	Cannot be locked	Always unlocked
DEU-Unlocked Fail Secure	Outside knob/lever when power is applied from the solenoid Outside key Inside knob/lever Latchbolt is deadlocked by an auxiliary latch	Removing power from the solenoid	Applying power to the solenoid; remains unlocked while power is on.	Cannot be locked	Always unlocked
NXEL-Locked Fail Safe	Outside knob/lever when power is removed from the solenoid Outside key Inside knob/lever Latchbolt is deadlocked by an auxiliary latch	Applying power to the solenoid; remains locked while power is on.	Removing power from the solenoid	Cannot be locked	Always unlocked
NXEU-Unlocked Fail Secure	Outside knob/lever when power is applied from the solenoid Outside key Inside knob/lever Latchbolt is deadlocked by an auxiliary latch	Removing power from the solenoid	Applying power to the solenoid; remains unlocked while power is on.	Cannot be locked	Always unlocked
TDEL-Locked Fail Safe	Outside key Outside knob/lever when power is removed from the solenoid. Inside knob/lever Latchbolt is deadlocked by an auxiliary latch	Applying power to the solenoid; remains locked while power is on. Deadbolt operated by: Outside key Inside thumb turn	Removing power from the solenoid Deadbolt and Latchbolt retracted simultaneously by: Inside knob/lever Outside knob/lever when power is removed	Cannot be locked	Always unlocked
TDEU-Unlocked Fail Secure	Outside knob/lever when power is applied from the solenoid Outside key Inside knob/lever Latchbolt is deadlocked by an auxiliary latch	Removing power from the solenoid Deadbolt operated by: Outside key Inside thumb turn	Applying power to the solenoid; remains unlocked while power is on. Deadbolt and Latchbolt retracted simultaneously by: Inside knob/lever Outside knob/lever when power is applied	Cannot be locked	Always unlocked
LEL-Locked Fail Safe	Outside knob/lever when power is removed from the solenoid Inside knob/lever Latchbolt is deadlocked by an auxiliary latch	Applying power to the solenoid; remains locked while power is on. Deadbolt extended by: Inside thumb turn	Removing power from the solenoid Deadbolt retracted by: Inside thumb turn Inside knob/lever retracts the deadbolt and latchbolt simultaneously Outside lever when power is removed	Cannot be locked	Always unlocked
LEU-Unlocked Fail Secure	Outside knob/lever when power is removed from the solenoid Outside key Inside knob/lever Latchbolt is deadlocked by an auxiliary latch	Removing power from the solenoid Deadbolt extended by: Inside thumb turn	Applying power to the solenoid; remains locked while power is on. Deadbolt retracted by: Inside thumb turn Inside knob/lever retracts the deadbolt and latchbolt simultaneously Outside knob/lever when power is applied	Cannot be locked	Always unlocked

NOTE: Powered by 12V DC. temperature control module is not needed.

^{*}A ridged lever/knob in a non-energized state.