

# Packages



**8310-3881**  
**Single Door Package - (1) Activation and (2) Safety Sensors with ANSI .10 Monitoring**

- Activation/Safety Sensor Package, Single Door
- Includes 8310-854 (2) Header Mount Activation Sensor, 8310-878 Monitored Safety Sensor kit (Used with Senior Swing only)

Alert: After November 2017, this package must be purchased for unknowing-act activation requirements in A156.10 for single door.



**8310-3883**  
**Senior Swing Single Door Package - (1) Safety Sensor and (1) Concealed Door Position Switch and (1) Relay Module**


- Activation/Safety Sensor Package, Low Energy Convenience
- Single Door, Includes 8310-804-1 Door Mount Safety Sensor (approach side), 8310-805C Door Position Switch (Concealed), 8310-845 Programmable Relay Module (Used with Senior Swing only)



**8310-3882**  
**Double Door Package - (2) Activation and (4) Safety Sensors with ANSI .10 Monitoring**


- Activation/Safety Sensor Package, Double Door
- Includes 8310-854 (2) Header Mount Sensor, 8310-879 Monitored Safety Sensor kit (Used with Senior Swing only)

Alert: After November 2017, this package must be purchased for unknowing-act activation requirements in A156.10 for single door.



**8310-3891**  
**Senior Swing Simultaneous Pair Package - (1) Header Safety Sensor and (1) Spacer and (4) Door Mount Safety Sensors and (2) Harnesses**

- Activation/Safety Sensor Package, Health Care I, Simultaneous Pair
- Includes 8310-877 Header Mount Sensor, 8310-877S Header Mount Spacer, 8310-804-2 (4) Door Mount Sensor (approach/ safety side), 8310-847 (2) Harness (Used with Senior Swing only)



**8310-3892**  
**Senior Swing Independent Pair Package - (2) Header Sensors and (2) Spacers and (4) Door Safety Sensors and (2) Harnesses**

- Activation/Safety Sensor Package, Health Care II, Independent Pair, Includes 8310-877 (2) Header Mount Sensor, 8310-877S (2) Header Mount Spacer, 8310-804-2 (4) Door Mount Sensor (approach/safety side), 8310-847 (2) Harness (Used with Senior Swing only)

NOTE: Not for use with Double Egress These two sensor packages must be used on installations with knowing-act activation only