


Large Format Interchangeable Core Cylinders



Interchangeable Core

For use with Corbin Russwin's 6-pin Interchangeable Core housings & shells.*




*CR8700 core must be used with 1078 or 3078 housings to maintain UL437 listing

Type	Finish
CR8500 - AP Type CR8600 - AS Type CR8700 - AHS Type	606 and 626 only


Note: All plugs and shells for LFIC cylinders are provided in 606 or 626. Mortise and rim housings are provided in the finish of the lock hardware order

Driver Assemblies

For use with LFIC cores



LFIC



CL3300



CL3100

Part No.	Driver Type
631F188	Driver, LFIC (114)
631F198	Driver, LFIC (138)
631F208	Driver, LFIC (112)
631F215	Driver S/A LFIC (134)
631F238	Driver, CL3300 Series
631F258	Driver, CL3100 Series

How to Order Examples

AS Security Interchangeable Core Ordered Separately

Quantity	Keyset	Cylinder	Keyway	Finish
50	AA1	CR8600	CRA1	606