



*In or Out...we make it Easy!®*

## This Kit Contains:



10 User Fobs with 10 Deletion Cards



1 Enrollment Card

**IMPORTANT:** Identify user name on matching Deletion Card before removing them from the wallet. Do not mix pairs of fobs/cards before writing on Deletion Card. This is a starter pack only. Additional fob packs (purchased separately) may be added to your system. Please contact your dealer for more information.

# 932-10KP Easy Read-Prox® 10 Card Pack

## 3 Special Function Cards:

PROXIMITY door  
open time card

The period that the door is unlocked for when a valid card is presented is set as follows: Present this card, the reader will beep, wait for the required period, present the card again, the beeping will stop.



1 Door Open  
Time Card

PROXIMITY fail  
open release card

This card is used with systems where a fail open electric release is used for safe operation in the event of a fire. Present the card to the reader to drive a fail open release or maglock. Present the card again to revert to fail closed operation.



1 Fail Open  
Release Card

PROXIMITY silent  
operation card

Present this card to silence the beeping noises made by the reader. Present the card again to re-enable the beeping noises.



1 Silent  
Operation  
Card