



ALARM LOCK
 345 Bayview Avenue
 Amityville, New York 11701
 CALL TOLL FREE: 800-ALA-LOCK
 (800) 252-5625

DL3000WP ADDENDUM TO PROGRAMMING INSTRUCTIONS

OI245 8/99

The wiring and power up information on page 6 of OI224B refers to wiring terminals. Wiring terminals are found on standard models only. The WP models do not have terminals -- they have wire leads and use a battery pack. Refer to the included installation manual (WI949C) for proper wiring.

