Functions

CL3100 Series

Outside Inside	Series/ Function	Type	ANSI No.	Function Description
	CL3110	Passage or Closet	F75	• Latchbolt by lever either side. • Both levers always free.
	CL3120	Privacy, Bedroom or Bathroom	F76A	• Throw-off latchbolt by lever. • Outside lever locked by push button on inside lever. • Outside lever unlocked by emergency release tool outside, by rotating inside lever or by closing door. • Inside lever always free.
	CL3120H	Hospital Privacy	—	• Outside lever locked by push button on inside lever. • Outside lever unlocked by rotating thumbturn on outside lever and releasing inside push button. • Rotating inside lever or closing door also unlocks outside lever.
	CL3129	Hotel or Motel	F93	• Deadlocking latchbolt by lever inside or by key outside. • Push button shuts out all keys except emergency key, and projects occupancy indicator in face of cylinder. • Push button released by turning inside lever. • Outside lever always locked. • Inside lever always free. • Not available with other manufacturers keyways • Pushbutton will not depress unless door is in closed position • Lockout key fixes pushbutton in locked position, shutting out all keys except emergency key. • Lockout key ordered separately.
	CL3132	Institutional or Utility	F87	• Deadlocking latchbolt by key either side. • Should be used only in office or room with multiple entries.
	CL3140NT	Exit Latch	F89	• Deadlocking latchbolt by lever inside. • Outside lever always locked. • Inside lever always free.
	CL3150	Half Dummy Trim	—	• Lever acts as pull only; no operation. • Lever is rigid.
	CL3151	Entrance or Office	F81	• Deadlocking latchbolt by lever either side, except when turn button locks outside. • Turning button locks outside lever, requiring key at all times. • Turning inside lever does not unlock outside lever until button is manually turned to unlocked position. • Inside lever always free.
	CL3152	Classroom Intruder	—	• Deadlocking latchbolt by inside lever or outside lever except when key inside or outside locks outside lever. • Key in either lever locks or unlocks the outside lever except when inside locks the outside lever - then only the inside key can unlock the outside lever. The outside key only retracts the latchbolt unless the outside lever is unlocked by the inside key. • Inside lever always free.

Indicates optional interchangeable core available; see Quick Codes, page 12.

Copyright © 2012-2019, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited. Patent pending and/or patent www.assaabloydss.com/patents.