

1131 Series Door Closers



General Information

1131 Series Door Closers

SARGENT ASSA ABLOY

Features

- Reversible "Non-handed"
- Full rack and pinion
- · High strength cast aluminum case
- Tri-packed for versatile mounting, inverted or parallel
- · Arm leverage adjustment
- · Heat treated high tensile springs
- One piece spindle heat treated for high strength
- Model available with spring adjustment

- Separate key controlled regulating valves for door closing and latching speed
- Two choices of finishes: EN for Aluminum Enamel, EB for Bronze Enamel to match 10B
- Valves are captivated to prohibit vandalism
- Adjustable backcheck valve is standard
- UL and ULC listed

- Typical uses hotel/motel guest rooms, assisted living centers, public housing, store fronts, office buildings
- Shall meet ANSI Grade 1 A156.4 requirements
- 15 year warranty
- · Parallel Arm Conversion bracket included
- · Mortise nuts and through bolts included
- · Auxiliary door stop required
- Optional full cover available
- Wood and machine screws provided as standard

Non Hold Open "RU" Package



The RU package is provided with non hold open arm which includes additional bracket that allows installer the choice of standard, parallel or top jamb application. Used on Rated and Non Fire rated doors.

Standard application shown above.

Series By Application

Description	Models
Adjustable from sizes 1 through 6: Door closers to meet handicapped	1131
requirements or for light through heavy weight interior doors	


Door Opening And Closing Cycle

The door opening cycle compresses the springs and positions the fluid to control the other cycles.

The backcheck cycle is controlled by the backcheck valve. This cycle slows the door before making contact with door stop. This can easily be turned off for doors that open more than 90°. (A door stop must be used to stop the door.)

Two separate valves control the door closing and latching speeds. The closing cycle controls the speed of door closing from the fully opened position to approximately five inches from the closed position. The latching cycle controls this last five inches.

- 1. Opening Cycle
- 2. Backcheck
- 3. Closing Speed
- 4. Latching Speed



Holder Arm "HU" Package



All applications for 1131 series closers shown in this catalog are also available with holder arms. Holding ranges are listed under the individual application. Specify "HU" arm when ordering.

The HU includes an extra bracket for field conversion from standard application to parallel arm application.

09/19


90393


Standard Mounting: Standard mounting provides maximum power allowing door to open 100°. Holding range of holder arm (hold open arm): 85°-100°.


Alternate Mounting: Closer installed to allow for 180° opening. Range of hold open arm from 85-180°


Maximum door opening: 180° if wall and trim conditions allow. Holding range of holder arm (hold open arm): 85°-180°. If butt, frame and wall conditions permit, closer will allow door to open 180°. Minimum top rail width required 2-1/2" for regular and hold open arm.













Parallel Arm Application

Closer mounts on top rail on stop side of door. Minimum top rail 5-1/4". As door opens, closer swings with door and gives full head room in door opening. For use on doors opening either in or out. Also used on two doors hung on the same frame with closer mounted between doors with a minimum of 5-1/4" in between doors. When two closers are used on different doors inside the same frame, the minimum door size is 46".



Alternate Mounting: Closer installed to allow for 180° opening. Range of hold open arm from $85\text{-}180^\circ$. Minimum width of stop required to mount foot bracket of arm is 1". Minimum mounting space required between two doors is 5-9/16" for regular arms and for holder arms.





Applications & Accessories

1131 Series Door Closers



Top Jamb Application


Closer mounts on top casing of push side of door.

As door opens, closer arm swings with door. Mounting for reveals up to 3".

Provides maximum power allowing door to open 100°. Holding range of holder arm (hold open arm): 85°-100°.

Alternate mounting: Closer installed to allow hinge to allow for 180° opening reveals less than 2". Range of hold open arm from 85-180°.

Minimum rail width on top casing required is 1-3/4". Minimum door rail width required to mount closer foot is 2-1/4", when frame without head stop is used (flush header).



Optional Accessories



Full size non-handed high Impact cover secured by two machine screws

Specify suffix "C" when ordering.

To order cover separately, use P/N 60-0535 x finish

Brackets (Included)

Regular Parallel "RU" Arm Bracket
Converts regular
standard arm to

parallel arm

Hold-Open "HU" Arm Bracket Converts the hold-open standard arm to hold-open parallel arm



581-1 Blade Stop Kit

Kit includes longer fasteners and 1/2" thick metal spacer for use with 1/2" blade stops commonly found on store front aluminum frames

Used with JP9 and JHP9 arms

