



Detex Corporation, 302 Detex Drive, New Braunfels, Texas 78130 (830)629-2900 /1-800-729-3839 /FAX(830)620-6711 E-MAIL: detex@detex.com INTERNET: www.detex.com

INSTALLATION INSTRUCTIONS FOR MORTISE 02DM, 02DMT, 02DMU OUTSIDE LEVER PULL TRIM



02 LEVER TRIM INSTALLATION INSTRUCTIONS

NOTES:

- 1. Mortise lock NOT supplied with TRIM device.
- 2. For a retrofit application, remove lock and device before installing new trim.
- 3. LHR installation shown (Reverse all steps for RHR).

STEP 1: PREP DOOR



STEP 2: INSTALL TRIM DEVICE



for cable routing.

Switching Handing from RHR to LHR

Machine Screw

Α

#1/4-20 x 1"

Lock washer

#1/4 lock washer

(Place trim on a clean surface with this view facing up)



 Use 1/8" Allen Wrench to remove screw

Pull back blocking plate Caution: Do not lose the brass shear pin located inside assembly.

Turn handle and plate 180°. Replace plate and tighten Allen screw