

INSTALLATION INSTRUCTIONS**565 / 665 Metal End Cap Kits**

FOR INSTALLATION ASSISTANCE CALL SARGENT AT 1-800-727-5477 • www.sargentlock.com

Contents include:

- (1) Hardware finished metal end cap
- (1) Mounting plate
- (3) Wood screws (to attach mounting plate)
- (2) Machine screws which match end cap finish (to attach end cap)

Instructions:

- (1) Remove existing end cap by removing cover screws.
- (2) Remove mounting plate by removing mounting plate screws.
- (3) Install new mounting plate using same holes in door. Mounting plate screws in back are same size and thread as old screws.
- (4) Install hardware finished metal end cap using two end cap screws.

