

IMPORTANT:

- An improperly installed or incorrectly adjusted door closer may cause property damage or personal injury; and will void product warranty.
- To avoid personal injury, **DO NOT DISASSEMBLE THIS DOOR CLOSER BODY.**
- Door closers must be securely fastened to a properly reinforced door and frame with fasteners provided.
- Door closers with a HOLD OPEN ARM are not permitted to be installed in fire door assemblies.
- Door and frame must be specifically templated for 85°, 90°, 100° or 110° door swing.

	S	ize of Doo		ERMINE			
Type of Installation	Interior	Exterior In -swinging	Exterior Out -swinging	Recommended Closer Size	**Max. Opening Force Ibs/f		ID OF DOOR:
Parallel Arm	2'4" 2'6" 3'0" 3'6" 4'0" 4'6"		2'6" 3'0" *3'6" *4'0"	1 2 3 4 5 6	8 14 16 22 24 26	RHR LEFT HAND DOOR	LHR RIGHT HAND DOOR

*DC6410 Series Recommended

**NOTE: These forces are for standard templating with bearing type hinges and do not account for pressure differentials and draft. Half size closers DC6410 are capable of being adjusted to next higher setting.



ASSA ABLOY 80-9360-6001-152 Rev. 07/08

2. Install Closer Bracket



4. A4 & A5 Backstop Arms Only Arms shipped for Left Hand Door. To change handing:

Remove Stop from Soffit with 5/32 Allen Wrench. Remove Filler Plug. Switch Stop and Filler Plug to opposite sides. Insert Stop and tighten. Push Filler Plug into hole.



6. Connect Arm To Closer

Using hex wrench provided, close (turn clockwise) CLOSING SPEED VALVE (see page 4 for location on closer). **DO NOT OVER TIGHTEN.**

- Open door to approximately 60°
- Using wrench on underside of spindle, rotate spindle approximately 135° toward hinge edge of door.
- Install arm on spindle at an approximate 90° angle to door.
- Reopen CLOSING SPEED VALVE.
- Install and tighten arm washer and screw.





ASSA ABLOY

80-9360-6001-152 Rev. 07/08



3. Mount Closer Body to Closer Bracket



5. Mount Arm to Door Frame



90

ARM

135[°] WRENCH 60° DOOR

Spring Power Adjustment

Locate spring power adjuster from Illustration below DC6400 Half Size Adjustment as Desired DC6200 Size 1 thru 6 Adjustment See Chart

DC6200 SPRING POWER ADJUSTMENT CHART

- All DC6200 closers are factory set at an approximate Size 3.
- Adjust closer as necessary for door size using this chart.
 Deadiustment may be required to guit providing conditions



Closing Speed Valve (3/32 Allen Wrench Provided) To adjust speed of door closing from fully open to a position 2" to 5" from closed, turn Closing Speed Valve CLOCKWISE to SLOW closing, COUNTER-CLOCKWISE to SPEED closing.

Latching Speed Valve (3/32 Allen Wrench Provided) After closing speed has been obtained, turn latching speed valve CLOCKWISE to SLOW latching or COUNTER-CLOCKWISE to SPEED latching for last 2" to 5" of door travel.

NOTE: Set combination of CLOSING and LATCHING speeds to between 3 and 7 seconds Use of door by handicapped, elderly or small children may require even greater closing time.

Delayed Action Valve (3/32 Allen Wrench Provided) Turn valve CLOCKWISE to SLOW closing, COUNTER-CLOCKWISE to SPEED closing. Delayed action may be adjusted from 20 seconds to 90 seconds, depending on degree of door swing. Delay occurs at the beginning of the door closing cycle from fully open down to 70°, where the closing speed valve then begins its control.

	Size of D	No. of Full	Equivalent		
Interior	Exterior In Swing	Exterior Out Swing	(360°) Turns Clockwise of Power Adjuster	Closer Size (Approx.)	
2'4" (712)	2'6" (764)		4	2	
2'6" (764)	3'0" (915)		8	3	
3'0" (915)	3'6" (1067)	2'6" (764)	12	4	
3'6" (1067)	4'0" (1219)	3'0" (915)	16	5	



Backcheck Location Valve (3/32 Allen Wrench Provided) Valve is closed, as shipped, from factory. To increase the degree of door opening where backcheck takes effect, turn valve counter-clockwise.

	VALVE	OCCURS AT					
	CLOSED	65°-70°					
	OPEN	95°-100°					
Degrees shown are approximate							

Backcheck Intensity Valve

Turn valve COUNTER- CLOCKWISE to reduce backcheck or CLOCKWISE to increase backcheck. (Backcheck should be set to give a soft cushioning action, not a sudden stop).

Installing Cover



Hold Open Operation (A2 and A5 Arms only) A quarter turn of the tee handle in either direction engages or disengages the hold open feature.







Copyright© 2005, 2008 Corbin Russwin, Inc., an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Corbin Russwin, Inc. is prohibited