

INSTALLATION INSTRUCTIONS

1. Select and determine degree of opening, hold open or dead stop from chart on back side of page.

- 2. Locate "A" and "B" dimensions on door and frame.
- 3. Install jamb bracket on stop strip.



4. Position door bracket on door with shock spring located towards pivot. Drill 3/8" diameter hole for first sex bolt as shown for dimension "A".



No. 8HD Series

Heavy Duty Surface Mounted

Door Stops and Holders

5. Be sure that door bracket is horizontal and holes are located on door 1-3/8" down from stop strip as shown. Drill 3/8" diameter hole for second sex bolt and install door bracket.



NOTES:

- All hollow metal doors and frames should be properly reinforced with 3/16" min. thickness x 12" min. length reinforcement plates.
- All drilling and tapping to be done by field men.
- Sex bolts furnished will be 3/8" diameter and will extend into door bracket.
- Suggest mounting door stop or holder first and then other hardware to clear. Contact factory if interference results with other hardware.
- · Left hand shown right hand opposite. (Note hole pattern in jamb bracket.)
- All dimensions are given in inches.
- Non-handed, reversible.

DOOR BRACKET COVER: If cover is provided, snap on to door bracket after screws have been tightened into sex bolts.

CONTROL KNOB: Turn control knob one half turn for hold open or stop only operation.

Screw Details											
Туре	Qty.	Description									
Door Bracket	4	1/4-20 x 1-1/4" FHMS and 3/8" Dia. Sex Bolts									
Jamb Bracket	4	1/4-20 x 3/4" FHMS or #14 x 1-1/2" FHWS									

RIXSON* ASSA ABLOY www.rixson.com TEMPLATE NUMBER DATE

OH80050A

No. 8HD Series Heavy Duty Surface Mounted Door Stops and Holders

TEMPLATE NUMBER OH80050B

Rixson® is a registered trademark of Yale Security Inc., an ASSA ABLOY Group company. Copyright© 2000, 2013, Yale Security Inc., a ASSA	A ABLOY Group company.
All rights reserved. Reproduction in whole or in part without the express written permission of Yale Security Inc. is prohibited.	

No. 8HD Series Heavy Duty Surface Mounted Door Stops and Holders

1. See other side for installation instructions.

2. Select proper dimensions noted below.

3. All drilling and tapping to be done in field.

4. All dimensions given in inches.

5. When using center hung pivots, check pivot manufacturer's compatibility prior to specifying.

For single acting doors only. Reversible, non-handed.

H.O. = Hold Open for Holders and Opening for Stops. D.S. = Dead Stop for Both Holders and Stops.

1¾ - 2% Butts & ¾ Offset Pivot	Device Number		Degree	85°				90°				95°				100°				105°					11	0 °	
				Н.О.		D.	D.S.		н.о. [S.	H.O.		D.S.		Н.О.		D.S.		Н.О.		D.S.		Н.О.		D.S.	
	H.O.	Stop	Door Opening	Α	в	Α	в	Α	в	A	в	A	в	A	в	A	в	Α	В	Α	в	Α	в	Α	в	Α	в
	8-226	8-236	$27\frac{1}{16} - 32\frac{1}{2}$	10 ⁷ 8	8 ¹ /8	11 ¹⁵ 11 ¹⁶	9 <u>16</u>	10 ⁵	7 <u>9</u> 716	11 ³ /8	8 ⁵ 8	9 ⁷ 8	$7\frac{1}{8}$	10 ⁷ 8	8 ¹ /8	$9^{\frac{1}{2}}$	$6^{\frac{3}{4}}$	10 ¹ /2	$\frac{3}{74}$	9 <u>1</u>	$6^{\frac{3}{8}}$	10 ¹ /8	$7\frac{3}{8}$	8 ¹³ 816	6 <u>16</u>	9 ¹³ 916	7 <u>16</u>
	8-326	8-336	32 <u>16</u> - 38 ³ /4	15 <u>16</u>	1016	16	11 ³ /4	14 <u>16</u>	1016	15 <u>16</u>	1116	13 ³	9 <u>1</u>	14 <u>3</u>	10 ¹ 2	13 ¹ /4	9	$14^{\frac{1}{4}}$	10	12 ³	8 <u>1</u>	13 ³	$9^{\frac{1}{2}}$	12 <u>7</u>	816	13 ³	9 <u>8</u>
	8-426	8-436	38 ¹³ / ₁₆ - 42 ¹ / ₂	19 ³	1316	20 ³ /4	14 <u>11</u>	18 ¹⁵	12 ⁷ 8	20 ¹	14	1816	12 <u>1</u>	19 <u>16</u>	13 <u>8</u>	17 <u>16</u>	11 ¹ 2	18 <u>1</u>	12 <u>7</u>	1716	11	17 <u>15</u>	11 <u>8</u>	1616	10 ¹ /2	17 <u>16</u>	11 3
	8-526	8-536	42 <u>9</u> - 48	22 <u>1</u> 6	15 <u>16</u>	23 ³	16 ³	21 ¹ /2	$14\frac{1}{2}$	22 <u>7</u>	15 <u>16</u>	20 ^{<u>11</u>}	13 ¹¹	21 <u>5</u>	14 ⁵	20	13	20 ⁷ /8	13 ⁷ 8	19 ³	12 ³	20 <u>5</u>	13 <u>5</u>	18 ⁷ 8	11 8	19 ³	12 ³ /4
1¾ - 2% Center Hung	Device Number		Degree	85°			90°			95°			100°			105°				110°							
				H.O. D		D.	.S. I		H.O. D.S.		S.	Н.О.		D.S.		H.O.		D.S.		Н.О.		D.S.		Н.О.		D.S.	
	Н.О.	Stop	Door Opening	A	в	Α	в	A	в	A	в	Α	в	A	в	A	в	Α	В	Α	в	Α	в	A	в	A	в
	8-226	8-236	27 <u>16</u> - 35	11 ¹¹	8 ¹⁵ 816	12 <u>16</u>	9 ¹³	11 <u>16</u>	8 <u>16</u>	12	$9^{\frac{1}{4}}$	10 ¹¹	7 <u>15</u>	11 <u>2</u>	$8^{\frac{3}{4}}$	10 <u>16</u>	7 <u>16</u>	11 <u>16</u>	8 <u>16</u>	9 <u>15</u>	7 <u>16</u>	10 ¹¹ /16	7 ¹⁵	9 <u>5</u>	6 <u>7</u>	10 <u>16</u>	7 <u>9</u> 716
	8-326	8-336	$35\frac{1}{16} - 41\frac{1}{2}$	15 ³	11 ¹ 2	16 <u>5</u>	12 ³	15 <u>16</u>	1016	1516	11 <u>11</u>	14 ¹ /2	10 ¹ /4	15 <u>16</u>	11 <u>16</u>	13 ¹⁵	9 ¹¹ 916	14 ³ /4	10 ¹ /2	13 ¹ 2	$9^{\frac{1}{4}}$	$14\frac{1}{4}$	10	13 <u>16</u>	8 ¹³	13 <u>13</u>	9 <u>9</u> 916
	8-426	8-436	41 <u>16</u> - 45	20 ³ /8	14 <u>16</u>	20 ¹ / ₄	15 <u>16</u>	19 <u>16</u>	13 ¹ 2	2016	14 <u>3</u>	18 <u>7</u>	12 <u>13</u>	19 <u>5</u>	13 <u>16</u>	1816	12 ¹ /8	19	12 <u>15</u>	17 <u></u> 8	1116	18 ³	12 <u>5</u>	17 <u>1</u>	1116	$\frac{7}{78}$	11 ¹³
	8-526	8-536	45 <u>16</u> - 48	23 <u>1</u> 6	1616	23 ¹⁵	1615	22 ¹ /8	15 ¹ /8	22 ^{<u>15</u>}	15 ¹⁵	21 <u>16</u>	14 <u>16</u>	22 ¹ /8	15 ¹ 8	20 ⁵ /8	13 <u>5</u>	21 <u>3</u>	14 <u>3</u>	20	13	20 ³ / ₄	13 ³	9 <u>16</u>	1216	20 <u>16</u>	1316

RIXSON[®] ASSA ABLOY

www.rixson.com

07-13